


# Getting Started

How to install your ines GPIB card



# Installation Guide

## Introduction

This booklet is a quick installation guide for an ines GPIB card for Microsoft® Windows® 2000/XP .

For a more detailed description of the installation, non-standard installations or other operating systems see the manual on the CD-ROM included.

## Installation

Always follow the instructions of the computer manufacturer for the installation of add-on cards.

- Insert the card into a free slot, turn on the computer and start Windows.
- Windows recognizes the new hardware.
- Insert the installation CD-ROM into your CD-ROM drive.
- Let the Hardware Wizard search for a driver and choose CD-ROM as source.
- After the Hardware Wizard has finished run *setup* from the installation CD-ROM. Follow the instructions of *setup* .
- Click Start/Programs/INES-488.2/Welcome for the next steps.

## License & Support

Read the license text file on the CD-ROM! By using the software you agree on the license terms.

Support information is available at the following location:  
<http://www.gpibworld.com/support>



INES Test and Measurement (Germany)  
[www.inesinc.com](http://www.inesinc.com) • [info@inesinc.com](mailto:info@inesinc.com)  
Phone +49 5723 916 250  
Fax +49 5723 916 252

Microsoft® and Windows® are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Product and company names listed are registered trademarks, trademarks or trade names of their respective companies. Our continual product improvement makes specifications subject to change without notice. © 2004